

# INSTALLATION INSTRUCTIONS FOR 11 Line U.S. Patent No. 6,626,018


**SARGENT**

**ASSA ABLOY**


FOR ASSISTANCE, CONTACT SARGENT AT 800-727-5477 or [www.sargentlock.com](http://www.sargentlock.com)

To view helpful video installation tips, scan the Microsoft® Tags with your mobile phone. Download the free mobile app at <http://gettag.mobi>.

| Item | Description                                   | Qty. |
|------|-----------------------------------------------|------|
| 1    | Inside Lever                                  | 1    |
| 2    | 6 Lobe Security Set Screw,<br>1/4-28 x 11/64" | 2    |
| 3    | Rose                                          | 2    |
| 4    | Rosette                                       | 2    |
| 5    | Inner Collar                                  | 1    |
| 6    | Inner Sleeve                                  | 1    |
| 7    | Bearing Assembly                              | 1    |
| 8    | Aligning Pin                                  | 1    |
| 9    | Outer Sleeve (with captive Collar)            | 1    |
| 10   | Cylinder                                      | 1    |
| 11   | Outside Lever                                 | 2    |
| 12   | Keys                                          | 1    |
| 13   | Latch Assembly                                | 4    |
| 14   | Screw, Flat Hd, #8-32 x 3/4"                  | 1    |
| 15   | Strike (800 shown)                            |      |



LATCHBOLTS ARE NOT INTERCHANGEABLE.



## 1 Door Preparation

- Fold template on door and mark hole centers
- Bore 2-1/8"
- Bore 1" hole
- Cut rectangular front recess

## 2



- Cut rectangular front recess

## 3

- Mark centerline on jamb
- Mark outline of strike
- Cut recess for latch bolt
- Install strike; secure with two screws
- IMPORTANT**  
Guardbolt stops on strike when door is closed

## 4 Lock Disassembly


1. Unthread collar and remove OUTSIDE sleeve
2. Remove aligning pin from bearing assembly
3. Separate latch from bearing assembly



## 5 Latchset Installation

Hold door open with door stop

1. Insert bearing assembly
2. Insert latch assembly
3. Insert aligning pin from secure side (outside) of door
4. Install latch plate screws. Do not tighten completely until lock installation is finished



## 6 Function Specific Instructions - Sleeve Assembly

**IMPORTANT:** Sleeves with colored driver tips require that the slotted cam be rotated allowing the spring loaded locking piece to move freely in and out of the outside sleeve

Driver Tips with red markings must match up before assembling lock

**PLEASE NOTE** — Some driver tips have two color markings for function identification

|                |                  |
|----------------|------------------|
| 11G54 - green  | 11U65 - blue     |
| 11G24 - yellow | 11G05 - only red |

Locking Piece must move in & out

Outside Sleeve

Driver Tip

Note: Outside sleeve has collar attached

Outside Sleeve

"Spring loaded position"


### See Specific Instructions Per Function. Identify Function On Box (Example: 11G05)

For functions not shown proceed to step 7

| Outside Sleeve                                  | Function Number | Function Description         | Inside Sleeve                                         |
|-------------------------------------------------|-----------------|------------------------------|-------------------------------------------------------|
| Align driver tips matching the painted sections | 04              | Storeroom/Closet             | Follow Step 7                                         |
|                                                 | 05              | Entrance/Office              |                                                       |
|                                                 | 16              | Classroom Security/Apartment |                                                       |
|                                                 | 17              | Utility/Asylum               | <p>Scan to see a video of this installation step.</p> |
|                                                 | 24              | Entry                        |                                                       |
|                                                 | 44              | Service Station              | Follow Step 7                                         |
|                                                 | 65              | Privacy/Bathroom             |                                                       |
|                                                 | 38              | Classroom Security           | Follow Step 7                                         |
|                                                 | 54              | Dormitory                    |                                                       |
|                                                 | 50              | Hotel/Motel                  | See A7608B                                            |
| See A7608B                                      |                 |                              |                                                       |

# 7


## Sleeve Installation



Scan to see a video of this installation step.


1. With driver tips aligned, insert outside sleeve first. Dimple must face door edge
2. Thread outside collar by hand. Tighten to bearing assembly with wrench
3. Insert inside sleeve. Dimple must face door edge
4. Thread inside collar by hand. Tighten to bearing assembly with wrench

**Caution: If excessive wrench torque is required, stop and check alignment of driver tips**



# 8

## Cam Orientation




Scan to see a video of this installation step.


1. Lock lever by button if applicable
2. Turn slotted cam until lever catch button can be depressed

**NOTE:** Dark colored cams on the inside designate for use with standard cylinders. Silver colored cams on the inside designate for use with I/C & R/C cylinders.

### Correct Cam Orientation for Standard Cylinder



### Correct Cam Orientation for IC/RC Cylinders




# 9

## Rose Installation


1. Slide rose over sleeves aligning tabs on rose with slots on bearing assembly
2. Hand tighten rosettes to door surface

**Caution: If excessive wrench torque is required, stop and check for cross-threading**

**Note:** Rosettes must be tightened simultaneously to ensure proper centering of lock on door.



Scan to see a video of this installation step.



## Function Specific Directions - Lever Installation

For functions not shown proceed to step 10

| Inside Sleeve                                                                         | Function | Function Description          | Outside Sleeve                                                                                              |
|---------------------------------------------------------------------------------------|----------|-------------------------------|-------------------------------------------------------------------------------------------------------------|
| Lock lever by button                                                                  | 05       | Entrance/Office               | Rotate cam until lever catch button can be depressed, holding cam in rotated position                       |
|                                                                                       | 24       | Entry                         |                                                                                                             |
|                                                                                       | 44       | Service Station               |                                                                                                             |
|                                                                                       | 65       | Privacy/Bathroom              |                                                                                                             |
|                                                                                       | 04       | Storeroom/Closet              |                                                                                                             |
| Rotate cam until lever catch button can be depressed, holding cam in rotated position | 17       | Utility/Asylum                |                                                                                                             |
| Rotate cam counterclockwise until it stops.                                           | 16       | Classroom Security/ Apartment | Rotate cam until lever catch button can be depressed                                                        |
|                                                                                       | 30       | Communicating                 | Rotate cam counterclockwise until it stops. Then rotate back 45° until lever catch button can be depressed. |
|                                                                                       | 38       | Classroom Security            | Rotate cam counterclockwise until it stops. Then rotate back 45° until lever catch button can be depressed. |
| Lock lever by button                                                                  | 54       | Dormitory                     | Rotate cam counterclockwise until it stops. Then rotate back 45° until lever catch button can be depressed. |
| See A7608B                                                                            | 50       | Hotel/Motel                   | See A7608B                                                                                                  |

Scan to see a video of this installation step.




Scan to see a video of this installation step.




## 10 Lever Installation

- For conventional cylinder, place cylinder into lever. Insert key and turn 45° CLOCKWISE to align cylinder tailpiece with deep slot in cam (see slotted cam illustration in step 8). For removable or interchangeable core, see separate instruction sheet (A7471).
  - Install outside lever. Push on until lever catch engages
- Note:** If outside lever won't secure in place, rotate key clockwise until lever catch is released.
- Secure with 6 lobe security set screw until flush with lever surface
  - Install inside lever. On 17 and 30 function, push on until lever catch engages.
  - Secure with 6 lobe security set screw until flush with lever surface
  - Complete tightening of two latchbolt screws
  - Check operation of levers and latchbolt before closing door



Scan to see a video of this installation step.




## 11 11G38 Classroom Security Function

**Function Description:** Inside lever is always unlocked. Inside key locks/unlocks outside lever. When inside key locks outside lever, outside key retracts the latchbolt but cannot unlock the outside lever.

Inside rose is marked with "Lock" and direction arrows to indicate locking direction

**INSIDE:**  
Rotate key CLOCKWISE TO LOCK.  
Rotate key COUNTER-CLOCKWISE TO UNLOCK




**Note:** If outside lever remains locked, rotate key on inside lever 360 degrees counterclockwise, and then rotate key on outside lever 360 degrees clockwise.

**OUTSIDE:**  
Rotate key COUNTER CLOCKWISE TO LOCK.  
Rotate key CLOCKWISE TO UNLOCK.

## 12 Cylinder Removal (Conventional)

- Remove 6 lobe security set screw
- Insert key and rotate 45° clockwise to release lever catch
- Depress lever catch and remove lever

Please Note: Removable and interchangeable core cylinders do not require removing the lever to install. See separate instruction sheet (A7471).



## 13 11U65 Outside Lever Removal

- Remove 6 lobe security set screw
- Lock outside lever by pushing in button on inside lever.
- Rotate slot on outside lever with flat blade screwdriver 45° to release lever catch and hold in place
- Depress lever catch and remove lever