

ITEM	PART NO.	DESCRIPTION	QTY
6 (Cont.)			
	82- Prefix Lockbodies		82-
	07-2654	04 Function	1
	07-2664*	05 Function	1
	07-2684*	37 Function	1
	FW- Prefix Standard Cylinder Lockbody (10-11-21-22-5C-5E-VA-V5- Only)		
	07-2651	04 Function	1
	07-2661*	05 Function	1
	07-2681	37 Function	1
	07-2691*	65 & 68 Functions (Emergency button must be ordered separately)	1
	FW- Prefix Removable Core Cylinder Lockbody (60-63-64- Only)		
	07-2655	04 Function	1
	07-2665*	05 Function	1
	07-2685	37 Function	1
	FW- Prefix Interchangeable Core Cylinder Lockbody (65-73-65-73-7P-70-72-73-73-7P- Only)		
	07-2656	04 Function	1
	07-2666*	05 Function	1
	07-2686	37 Function	1
	FW- Prefix Keso Cylinder Lockbody 80-, 82-, F1- Only)		
	07-2657	04 Function	1
	07-2667*	05 Function	1
	07-2687	37 Function	1
7	07-0100	Cardboard Spacer	1
8	07-0105	Support plate-outside	1
9	07-2426	Outside Rose Spring Assembly	1
	07-2428	15-3 Function Blank Rose	1
10	10-0019	Cylinder Spacer	1
11	10-0032	Cylinder Retainer - For Standard	2
	10-0058	Cylinder Retainer - For Removable Core/Interchangeable Core/Keso	2
12	13-3266*	Std. Cylinder - All Functions Except 50 Function	1
13		Keys (Specify per key system)	2
14	10-0043	Lever Retainer Push Pin	1
15	07-2430*	2-3/4" Backset (Deadlocking Latch)	1
	07-2432*	2-3/4" Backset (Latch)	1
	07-2431*	2-3/8" Backset (Deadlocking Latch, 20- Prefix)	1
	07-2433*	2-3/8" Backset (Latch, 20- Prefix)	1
16		Flat Head Standard (8-32 X 3/4") (01-5000)	4
	*	Flat Head Standard (28 Prefix) (8-32 X 3/4") (10-2070)	2
		Flat Head (28 Prefix) (12-24 X 3/4") (01-5002)	2
17	08-0312*	Strike No. 600 (Part # does not include screws)	1
	08-0066*	Strike No. 808 (Prefix 28)	1
	05-0013*	Strike No. 505 (Prefix 14-)	1

ITEM	PART NO.	DESCRIPTION	QTY
18	08-0055	Strike Box - Standard	1
	77-1141	Strike Box - Optional for 28- Prefix	1
20	10-2052*	Screw Pack: Standard (Includes Item Numbers 3, 13, 15 and 17)	1
	10-2070*	Screw Pack (28 Prefix) (Includes Item Numbers 3, 13, and 15)	1
21	07-0270	Through-bolt screws	2
22	07-2492	Screw Packs for 10U93 Function Surface screws (2) and push pin	1
23	07-2492	Screw Pack for 10U94 Function Surface screws and push pin	2
24	08-2842*	Blank Front Plate Pack (94-2 Function)	1